


User's Manual

DCU 305 R2 Control Unit configuration tool





Contents

| | | |
|----------|-------------------------------------|-----------|
| 1 | Introduction | 4 |
| 1.1 | Important information | 4 |
| 1.2 | System requirements | 4 |
| 1.2.1 | Minimum PC requirements | 5 |
| 1.3 | Installation of Rudolf R2 | 5 |
| 1.3.1 | Uninstall previous installations | 5 |
| 1.3.2 | Installation | 6 |
| 2 | Menu Overview | 7 |
| 2.1 | File | 7 |
| 2.1.1 | N ew | 7 |
| 2.1.2 | O pen | 8 |
| 2.1.3 | S ave | 8 |
| 2.1.4 | Save A s... | 8 |
| 2.1.5 | C lose | 8 |
| 2.1.6 | E xport as Text | 8 |
| 2.1.7 | E -mail... | 9 |
| 2.1.8 | P rint... | 9 |
| 2.1.9 | E xit | 9 |
| 2.2 | C ommunication | 9 |
| 2.2.1 | L oad from control unit... | 9 |
| 2.2.2 | T ransmit to control unit... | 10 |
| 2.2.3 | R etrieve log... | 11 |
| 2.3 | S ettings | 13 |
| 2.3.1 | B ackup System Settings... | 13 |
| 2.3.2 | C ontrol unit Clock | 14 |
| 2.3.3 | S ervice | 14 |
| 2.3.4 | O ptions... | 15 |
| 3 | Buttons | 17 |
| 4 | Configuration Sections..... | 18 |
| 4.1 | M ain | 19 |
| 4.1.1 | Main Operation Mode | 19 |
| 4.1.2 | Control Unit Language | 21 |
| 4.1.3 | Port P3 Functionality | 21 |
| 4.1.4 | Display Backlight Delay | 21 |
| 4.1.5 | Inverting LCD on Alarm | 22 |
| 4.1.6 | Warning Requires Acknowledge | 22 |
| 4.1.7 | Classifiable Project | 22 |
| 4.1.8 | J1939/CAN & J1708/J1587 support | 22 |
| 4.2 | S witch | 23 |
| 4.2.1 | Input Channel | 24 |
| 4.2.2 | Terminal | 24 |
| 4.2.3 | Active | 24 |
| 4.2.4 | Description | 24 |
| 4.2.5 | Action Type | 24 |
| 4.2.6 | Switch type | 24 |

| | |
|--|-----------|
| 4.2.7 Warning/Alarm/Shutdown on RUN only | 25 |
| 4.2.8 Initial delay | 25 |
| 4.2.9 Broken Wire Detection | 25 |
| 4.2.10 Delay before alarm/shutdown | 25 |
| 4.2.11 Additional Switch Inputs | 26 |
| 4.3 Analog In | 27 |
| 4.3.1 Add a new sensor | 27 |
| 4.3.2 Active | 28 |
| 4.3.3 Input Type | 28 |
| 4.3.4 Description | 28 |
| 4.3.5 Sensor Range | 28 |
| 4.3.6 Units | 28 |
| 4.3.7 Limit | 28 |
| 4.3.8 Action Type | 29 |
| 4.3.9 Double Scale | 29 |
| 4.3.10 Above or below limit | 30 |
| 4.3.11 Action on RUN only | 30 |
| 4.3.12 Initial delay | 30 |
| 4.3.13 Delay before Warning/Alarm/Shutdown | 30 |
| 4.4 Standby operation | 31 |
| 4.4.1 Initial Start Delay (Preheat timer) | 31 |
| 4.4.2 Cranking Time | 32 |
| 4.4.3 Delay between Start Attempts | 32 |
| 4.4.4 Number of Start Attempts | 32 |
| 4.4.5 Delay before disconnecting Gen. Breaker | 32 |
| 4.4.6 Cooling time | 32 |
| 4.5 Start/Fuel | 33 |
| 4.5.1 Initial Start Delay | 33 |
| 4.5.2 Cranking Time | 33 |
| 4.6 Speed sensor | 34 |
| 4.6.1 Pickup Information | 34 |
| 4.6.2 Pickup One/Two RPM Sender | 34 |
| 4.6.3 Ready to take Load | 35 |
| 4.6.4 Nominal/Max Speed | 35 |
| 4.6.5 Overspeed | 35 |
| 4.6.6 RUN Detected At | 36 |
| 4.6.7 Run Detection Delay | 36 |
| 4.6.8 Additional RUN Detection | 36 |
| 4.6.9 Speed Relays | 36 |
| 4.7 Battery | 37 |
| 4.7.1 Start Battery Voltage | 37 |
| 4.7.2 Low Battery Voltage Alarm | 37 |
| 4.7.3 Delay before Alarm | 37 |
| 4.8 Info | 38 |
| 4.8.1 Fields | 38 |
| 4.9 Relays | 39 |
| 4.9.1 RK-60 | 39 |
| 4.9.2 RK-66 R2 | 39 |
| 4.9.3 MK-6 and MK-14 | 39 |
| 4.9.4 Signals to the optional Relay Cards | 40 |
| 4.9.5 Available configurable signals | 41 |
| 4.9.6 Disable Broken Wire Alarm on Terminal 44 | 42 |

Document revisions

| Date | Revision |
|----------------|---|
| March 2001 | Release |
| March 2002 | Support for control unit firmware 4.25 and above |
| November 2002 | Added |
| May 2005 | CAN / diagnostic info added for 4.35 and above |
| July 2005 | Restart possibility after downloading added for 4.37 and above. |
| September 2006 | Described the new function Additional Run detection delay |

Copyright © Auto-Maskin AS, 1998-2006

Information given in this specification may change without prior notice.

This document must not be copied without permission from Auto-Maskin AS.

Title: Rudolf R2 User's Manual

Document order no: 09326

Revision: September 2006

All trademarks acknowledged.

Related documentation:

- *DCU 305 R2 User's Manual, Eng* *Article 06322*
- *DCU 305 R2 Communication Manual, Eng* *Article 06324*
- *DCU 305 R2 Installation Manual* *Article 06325*

1 Introduction

This document describes the Rudolf R2 and Rudolf R2 Light software for PC.

Rudolf R2 is the PC parameter software used to completely customise the **DCU 305 R2** range of Diesel Engine control units; hereafter referred to as the *control unit* only.

Note: Rudolf R2 is backward compatible and new versions completely replace earlier releases and versions.

Rudolf R2 is hereafter referred to as *Rudolf* only.

1.1 Important information

Rudolf is a powerful configuration tool that can completely change the current behaviour of the control unit.

Make sure you know your system well and use precaution whenever changing critical parameters in an installed system.

1.2 System requirements

Rudolf runs under Microsoft® Windows® 95/98/ME and Windows® NT/2000/XP, and occupies ~30MB of the harddisk space.

Note: Rudolf will *not* run on Windows 3.x.

The project files occupies 2-3k bytes only, and can easily be emailed between organisations.

1.2.1 Minimum PC requirements

A PC equipped with a Pentium processor running at 200MHz.

- Windows® 95/98/ME: 32MB RAM
- Windows® NT/2000/XP: 64MB RAM

Use a color screen with 800 x 600 dpi resolution or better.


Rudolf is delivered on a CD, so make sure the PC is equipped with a CD-drive.

1.3 Installation of Rudolf R2

1.3.1 Uninstall previous installations

Before installation, be sure to uninstall any previous copies of Rudolf.


Insert the CD-ROM in the drive. Run the SETUP.EXE file.



Select Remove and follow the guidelines from the uninstall program.

1.3.2 Installation

Close all other programs before installation. Insert the CD-ROM in the drive. Run the SETUP.EXE file.




Follow the guidelines on screen as given by the Setup program.

2 Menu Overview

2.1 File

The file menu is used for creating new project files, opening existing project files and saving current files.



The project files are small (2-3k bytes) and their extension is RDF, for instance MYFILE.RDF or PROJECT 173.RDF.

2.1.1 New

Alt+F+N


Select File-New to create a new project. The new project file has default values for most parameters.

Often, it is faster to open an earlier project that is similar, modify it, and save it with a new name.

2.1.2 Open

Alt+F+O

Select File-Open to open a previous project. The following dialog appears:



Select a file with the .RDF extension, and click Open.

2.1.3 Save

Alt+F+S

Select File-Save. If this is the first time the project is saved, Rudolf will prompt for a file name.

Type a file name. The extension .RDF is added automatically.

2.1.4 Save As...

Alt+F+A

This menu is used when saving a project with a new name.

Type the new name and press Save.

2.1.5 Close

Alt+F+C

This closes the open file. If it is not saved, Rudolf will prompt you to save it.

2.1.6 Export as Text

Alt+F+E

The complete project setup can be exported to a text-file. The text-file can easily be included into a word-processor document.

2.1.7 E-mail...

Alt+F+M

Select this option to send the opened Rudolf file as e-mail. This requires an installed version of Microsoft Outlook®.

2.1.8 Print...

Alt+F+P

Select this option to get a paper printout. It is possible see a preview before printing.



2.1.9 Exit

Alt+F+X

Select File-Exit to quit Rudolf. If the current project is not saved, you will be prompted to do so.

2.2 Communication

This menu handles *up- and download* of project files between the PC with Rudolf and the control unit.


Connect the Rudolf Cable between the control unit and the PC.

2.2.1 Load from control unit...

Alt+C+L

Receive the project currently in a control unit to Rudolf. This takes ~10 seconds.

The following dialog will appear:



Opening Communication port

Rudolf opens the PC communication port, Com1 – Com4.

If the selected port is in use by another program, this operation fails. If no port is selected, Rudolf brings up a dialog that makes you select a port.

Connecting to control unit

Rudolf makes sure that a control System is connected to the PC.

If it fails, make sure the right cable is connected and that the control unit is powered.

Receiving Data...

Rudolf receives the project currently in the control unit. If it fails, there is a bad cable connection between the PC and the control unit.

Verifying Data...

After receiving all data, Rudolf reads the control unit again to make sure all data is correct. If it fails, there is a bad cable connection between the PC and the control unit.

Completing


Rudolf informs the control unit the upload is finished and closes the PC communication port.

2.2.2 Transmit to control unit...

Alt+C+T

Transmit the open project to the control unit. This takes approx. ~10 seconds.

The following dialog will appear:



Opening Communication port

Rudolf opens the PC communication port, Com1 – Com4.

If the selected port is in use by another program, this operation fails. If no port is selected, Rudolf brings up a dialog that makes you select a port.

Connecting to control unit

Rudolf makes sure that a control System is connected to the PC and prepares the control unit for reception of a new Project.

If it fails, make sure the right cable is connected and that the control unit is powered.

Make sure the unit is in the READY state before transmitting.

For security reasons, it is not possible to send a new project if the engine is running. Connection will then fail.

Transmitting Data...

Rudolf sends the project to the control unit. If it fails, there is a bad cable connection between the PC and the control unit.

Verifying Data...

After sending all data, Rudolf read the control unit and makes sure all data is correct.

If this fails, there could be a bad cable connection between the PC and the control unit. Check the cable and try again.

Completing

Rudolf tells the control unit the download is finished and closes the PC communication port.

Note: Power the control unit off by removing the 24 volt supplies, then on again. The control unit is now ready to use with the new configuration.

If the control unit has Software version : 4.37 or later, then first holding the lamp test and alarm log keys for a while, and when the DEBUG screen has appeared, holding the Standby key until the display turns black, will achieve the same.

2.2.3 Retrieve log...

Alt+C+R

The control unit stores all events in a built-in log. This command will read the entire log and open it in Notepad on your PC.


Connect the Rudolf Cable between your PC and the control unit.



Included in the log are the project information and the counters.

2.3 Settings

This menu has a collection of useful submenus with settings that can be made in the control unit.




The built-in log and the counters can be reset to zero. This requires a password that can be obtained from your supplier.

2.3.1 Backup System Settings...

Alt+E+B

On some control units (R2), you are prompted to set the backup parameters on the control unit after a new configuration is downloaded.


Selecting this menu brings up the configuration again.



2.3.2 Control unit Clock

Alt+E+O

Some control units (R1) has a built-in real time clock that keeps track of time. When commissioning, it may be necessary to adjust the clock.



Type the date in the format dd mm yyyy (date month year) and time in the format hh mm (hours minutes).

Seconds are adjusted to zero when OK is selected.

Use UTC time as ships may travel across timezones.

Synchronise with Windows Clock (UTC)

If selected, the time in the control unit will match the current UTC time in the PC.

Press OK to download the new time to the control unit.

2.3.3 Service

Shift+Ctrl
Click Settings
Click Service

Or select Expert Mode...

Behind this hidden menu there are options for deleting the built-in log, and reset the built-in counters.

Follow the guidelines in the margin to access the menus.

Two choices appear:

- Delete Log
- Reset counters

A password is required to use actually delete or reset anything.

For passwords, contact your distributor.


2.3.4 Options...

A number of installations are made here, for instance:

2.3.4.1 Rudolf Mode


Choose between Normal Mode and Expert Mode.

In Expert Mode, only a minimum of dialogboxes is shown to speed up the configuration.




2.3.4.2 File Open/Save

The default file open/save folder can be set here.




2.3.4.3 Rudolf R2 Com. Port

Select the PC/laptop communication port to be used by Rudolf. Most often, this is COM1.



3 Buttons

A number of common tasks are quickly accessible using the buttons located under the menu string.




The first three buttons are common in the Windows environment and are **New** configuration, **Open** an existing configuration and **Save** the current configuration.

- Pressing the *green* arrow button will read the project currently in the control unit into Rudolf. The project may then be saved to a file.
- Pressing the *red* arrow button will transmit the project currently in Rudolf to the control unit.
- The printer button will print the documentation on your printer.
- The rightmost button is the Help button and brings up the Rudolf Help file.

4 Configuration Sections

The configuration is sorted into *tab* sections as follows:



The TAB sections

Note: The ‘Standby Operation’ tab changes to ‘Start/Fuel’ if selecting *Propulsion mode* in the Main tab.


The sections can be completed in any order, but it is normal to start with Main and then Switch and Analog In. The configurations made here will appear in the Relays section.

When a configuration is made and saved, it can be reused.

4.1 Main

Alt+M

The main tab lets you select the main operation mode and the control unit language.



4.1.1 Main Operation Mode

Four main operation modes can be selected as follows:

- Emergency
- Auxiliary
- Combined
- Propulsion

The Emergency, Auxiliary and Combined mode is supported in the DCU 305 A unit.

The Propulsion mode is supported in the DCU 305 P unit.

Note: Rudolf will *not* download the Emergency, Auxiliary and Combined modes into the Propulsion version (P) of the control unit, and vice versa.

1) Emergency Mode

*Shutdown for overspeed only,
all others disabled*

The control unit is prepared for Emergency operation mode. Shutdown is *disabled* for all inputs, regardless of the chosen action type.

Shutdown is *enabled* for Overspeed only.

2) Auxiliary Mode

All shutdowns enabled

The control unit is prepared for Auxiliary operation mode. Shutdown is *enabled* for all inputs set up to set shutdown, including Overspeed.

3) Combined Emergency/Auxiliary Mode

*Shutdowns are enabled in
Manual mode*

This is useful when the gen. set is used as a combined Emergency and Auxiliary gen. set.

The control unit switches between Emergency and Auxiliary operation mode depending on the state of the Standby button as follows:

Standby: Emergency operation mode. Shutdowns *disabled*.

Manual: Auxiliary operation mode. Shutdowns *enabled*.

4) Propulsion mode (control unit type P)

All shutdowns enabled

The control unit is prepared for Propulsion operation mode. Shutdown is *enabled* as for Auxiliary mode of operation.

4.1.1.1 The Operation Modes in table format

The four possible modes of operation of the control unit is summarised in this table:


| | Manual | Standby |
|-------------------|--------|---------|
| Emergency | | |
| Auxiliary | ✓ | ✓ |
| Combined | ✓ | |
| Propulsion | * | * |

✓ = Shutdowns enabled

* = Not applicable (no Standby/Manual button)

4.1.2 Control Unit Language

The control unit has a number of built-in alarms and messages. These are displayed in one of 11 different available languages.



The currently supported languages are:

- Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Portuguese, Spanish and Swedish.

Additional languages may appear in the future.

Note: Only the built-in texts are changed when switching language. Any self-defined text for sensors and switches must be translated manually.

4.1.3 Port P3 Functionality

Choose between *Communication* and *Log to Printer*.

4.1.3.1 Communication

Select Communication if the port is to be used towards a slave panel. Also, set the ID-number.

4.1.3.2 Log to Printer

Select Log to Printer if a printer is connected. This prints all the log events to the printer.

Note: The printer must have a serial port set to 9600, 8, 1, odd parity.

4.1.4 Display Backlight Delay

The time before the LCD-backlight shuts off is set here.

Typical: 3 hours

Range: 1 – 59 minutes, or
1 – 194 hours

Requires control unit firmware version ≥ 4.0 . Otherwise, it is fixed to 1 hour.

4.1.5 Inverting LCD on Alarm

Checking this option gives an inverting (flashing) LCD on Alarm.

4.1.6 Warning Requires Acknowledge

Select this option to have events configured as Warning needing an Acknowledge to disappear.

Uncheck to have Warnings disappear by itself.

4.1.7 Classifiable Project

Check this option (default checked) to make Rudolf verify that no options not allowed by the classification societies are made.

Here, these include:

- In the Switch section, it is not possible to select Shutdown on switches 7-12 (as these are not covered by the built-in backup system).
- In the Switch section, if a Shutdown is selected on channel 1-6, the option “Broken Wire Detection” must also be selected.
- In the Analog In section, it is not possible to select Shutdown on a falling signal (as a broken wire will give shutdown).

4.1.8 J1939/CAN & J1708/J1587 support

Selecting this option gives access to the supported messages in the J1939/J1587 protocols, in the optional CAN/J1587 hardware.

If you don't know what this is, just leave it unchecked.

Select the Mid nnn “Change” box to specify the MID for J1587.

If you use CAN and want to use Diagnostic, then enable it.

The “Diagnostic” should normally not be configured :

If you have one single diagnostic you do not get rid of you may specify its SPN here. You will then get rid of the diagnostic alarm/warning when it's only that SPN being reported.

The virtual diagnostic “Protect Lamp” gives alarm as default. You may change that, to give only Warning.

4.2 Switch

Alt+W

The switch tab is displayed below, together with all the possible settings for switch channels.

In the picture below, channel 1 is selected. Channel 1 uses terminal 7 on the wire terminal card RK-66 R2.

Clicking anywhere on that line will select channel 1. Then click *Active* to enable it and complete the fields.

The terminal number where the wires are connected

The channel number

Red text indicates the channel is not activated

| Channel | Terminal | Description |
|---------|----------|---------------------|
| 1 | 7 | LOP Low, Shut Down |
| 2 | 8 | CWT High, Shut Down |
| 3 | 9 | CW Flow, Shut Down |
| 4 | 10 | |
| 5 | 11 | LOP Low, Alarm |
| 6 | 12 | CWT High, Alarm |
| 7 | 13 | CW Level, Alarm |
| 8 | 14 | Fuel leakage, Alarm |

7 Active

Active

Input Type: Switch

Description: LOP Low, Shut Down

Action: Shutdown after 2 Seconds

Switch Type: Normally Open

Shutdown on RUN Only

Initial Delay: 15 Seconds

Broken Wire Detection

Additional Run Detection

Additional Switch Inputs:

Terminal 61: []

Terminal 62: []

- Above, channel 1 is selected. The normally open switch is connected between terminal 7 and 0V.
- Here, the alarm text “LOP Low, Shut Down” will appear two seconds after the switch opens.
- This channel is excluded when the engine is at standstill, and comes into operation 15 seconds after the engine has started.
- Further, this channel indicates that the engine is running – together with the rpm.

4.2.1 Input Channel

The input channel number. There are 12 channels altogether.

Any sensor can be connected to any channel, but we recommend to connect shutdown switches on channel 1..6, as these have broken wire detection and backup if the main microcontroller fails.

Warning and alarm switches are preferred on channels 7..12.

4.2.2 Terminal

The wire terminal number on the RK-66 R2 wire terminal card, where the sensor wire is connected. It is listed for reference only.

4.2.3 Active

This enables the input channel for use. Any channel can be enabled () or disabled ()

Disabled channels will never give alarms. Disabled channels with a text description are shown in red.

4.2.4 Description

User's text that describes the sensor, or its function. The text can be up to 30 characters long and may consist of numbers and, to some extent, national characters.

Rudolf will not allow typing of characters that the control unit is unable to display.

4.2.5 Action Type

Select Shutdown if you want the gen. set. to stop when this sensor is outside limits. Select Alarm otherwise.

Warning is used for a pre-warning before the alarm is set. The warning lamp follows the sensor, and will illuminate when the sensor is outside limits.

When the sensor is back within limits, the warning will disappear, without pushing the acknowledgement button. The warning is also available on the MK-6 or MK-14 optional relay card.

All Warnings will trigger the Common Warning Relay, if defined. See the chapter about relay functions on page 39.

All alarms will trigger the Common Alarm relay, and all Shutdowns will trigger the Common Shutdown relay.

4.2.6 Switch type

- Warning and Alarm uses Normally Closed contacts (NC).
- Shutdown uses Normally Open contacts (NO).

Warning, Alarm or Shutdown

It is possible to change that in this menu, although Rudolf suggests the most commonly used switch type for Warning, Alarm and Shutdown as above.

Switches for shutdowns shall be of type NO, as a broken wire should not initiate a shutdown.

4.2.7 Warning/Alarm/Shutdown on RUN only

If selected, the Warning/Alarm/Shutdown activates only if the engine is running.

4.2.8 Initial delay

An initial delay is possible only if “Warning/Alarm/Shutdown on RUN only” is selected.

- This is typically used on oil pressure sensors/switches.
- The amount of time after the engine has started (RUN is detected) until the channel is activated.

Typical value: 10-15 seconds

4.2.9 Broken Wire Detection

This feature can be applied on channels 1-6, if it is a shutdown channel.

- A **10k** ohm resistor must be connected in *parallel* with the actual switch.
- Refer to the control unit manual for further details.

4.2.10 Delay before alarm/shutdown

When the sensor is outside limit the control panel issues a warning, alarm or shutdown (depending on what is configured) after this amount of time.

Typical value: 2 seconds

4.2.11 Additional Switch Inputs

Terminals 61 and 62 on the RK-66 R2 wire terminal card are configurable.

LCD Light On: Activates the LCD backlight when it has been automatically turned off.

LOCAL Mode: The control unit is set to Local Mode.

Standby: The control unit is set to Standby.

Start Disabled: The control unit is set to Start Disabled.

All functions are activated by connecting to 0V.

4.3 Analog In

Alt+A


The analogue tab is displayed below, together with all the possible settings for analogue sensors.

The sensors must submit the industrial standard 4-20mA signal.

4.3.1 Add a new sensor

Select an available input channel by clicking in the window above it. In the figure below, channels 1-5 are in use.

Channel 6 is the next available sensor.



In the above example, channel two is highlighted and selected.

- A temperature sensor in the range 0 – 200C is connected between terminal 21 and 22.
- Terminal 21 is the 24VDC supply to the sensor, whereas terminal 22 is the 4-20mA input signal from the sensor.

- The alarm “Cooling Water Temp.” appears two seconds after the temperature exceeds 92 degrees C.

4.3.2 Active

This enables the input channel for use. Any channel can be enabled () or disabled () .

If the channel is disabled, the bargraph will not be displayed.

4.3.3 Input Type

This may be 0-20mA or 4-20mA.

On channel 1 only, 0-10V can be selected.

4.3.4 Description

The text that describes the sensor, or its function. The text can be up to 30 characters long and may consist of numbers and, to some extent, national characters.

Note: Although you can type up to 30 characters, we recommend a maximum of 20 characters, as this gives a nicer view.

Rudolf will not allow typing of characters the control unit is unable to display.

4.3.5 Sensor Range

The sensor range, as given on the sensor, must be completed for the meter to display correctly. The range can be set with one decimal.



The 4mA signal will equal the minimum (here 0 Bar) and 20mA will indicate the maximum (here 10 Bars) on the control unit meter.

- The range is –3000..3000.

4.3.6 Units

Select a predefined unit or type a new. Maximum four characters. This will be displayed at the end of the meter in the control unit.

4.3.7 Limit

Optionally, type a limit for the meter, inside the set sensor range. This will be displayed on the meter as a vertical bar.

The limit can be set with one decimal.

4.3.8 Action Type


None: No setpoints are set. The analog value will be displayed only.

Warning: Does *not* need acknowledge. Activates the common warning relay.

Alarm: Needs acknowledge. Activates the common alarm relay.

Shutdown: Needs acknowledge. Stops the engine. Activates the common alarm *and* common shutdown relay.

RPM dependent...: The setpoint varies with the current rpm.



Here, the Lub Oil Pressure alarm setpoint varies as follows:

- 0.8Bar @ <600rpm
- 2.5Bar @ >1500rpm
- Linear setpoint between 600rpm and 1500rpm

Note: To make a ramp function, just make the two rpm-values equal.

4.3.9 Double Scale

Ticking this option *doubles* the *size* of the bargraph.

If for instance, the engine oil pressure ranges from 0-6 bar, and the sensor range is 0-18 bar, the bargraph value will be small compared with the full size bargraph (max 6/18bar or 1/3 of the full size).

Doubling the scale will enlarge the bargraph value to 2/3 of the full scale, giving a better view.

The number readout is not changed.

4.3.10 Above or below limit

This controls the sensor triggering on a rising or falling signal.

- If it is a *temperature sensor*, an action is normally required on a *rising* signal. Select *When Above Limit*.
- If it is an *oil pressure sensor*, an action is required on a *falling* signal. Select *When Below Limit*.

Note: *Shutdown when below limit* is not allowed in a classified installation, as a broken wire will initiate the shutdown. Rudolf warns about this.

4.3.11 Action on RUN only

If selected, the warning/alarm/shutdown activates only if the engine is running.

This tickbox is disabled (grey) if neither an alarm nor a shutdown has been enabled for this channel.

4.3.12 Initial delay

This is available only if “Action on RUN only” (see above) is selected.

It’s the amount of time after the engine has started until this channel is monitored.

Typical: 15 seconds

Range: 0 – 255 seconds

4.3.13 Delay before Warning/Alarm/Shutdown

When the sensor is outside limit, it gives an alarm/shutdown after this amount of time.

Typical: 2 seconds

Range: 0 – 255 seconds


4.4 Standby operation

Alt+T

This tab controls parameters for automatic start and stop of the Gen. Set. when the control unit is set to Standby.

Note: This tab is available only for the *Auxiliary*, *Emergency* and *Combined* modes of operation, as selected in the Main tab.

The Standby Operation Tab displaying typical (default) values



4.4.1 Initial Start Delay (Preheat timer)

When the control unit receives the automatic-start “blackout-signal”, it delays this amount of time before the first start attempt.

Note: If using the Preheat function (found in Relays), this is also the preheating timer. The preheat relay then activates in this period.

Typical: 1 second (start delay), 10 seconds (preheat)

Range: 1-255 seconds

4.4.2 Cranking Time

The amount of time the starter motor is cranking the diesel engine in Standby mode of operation.

Typical: 7 seconds

Range: 2 – 20 seconds

Note: Too long start attempts may damage the starter motor or empty the start battery.

4.4.3 Delay between Start Attempts

This is the amount of time between each start attempt when set to Standby mode.

Typical: 7 seconds

Range: 2 – 60 seconds

4.4.4 Number of Start Attempts

The total start attempts before issuing the Start Failure alarm.

Typical: 3 attempts

Range: 1 – 20 attempts

Note: Too many (and/or too long) start attempts may discharge the starter-battery.

4.4.5 Delay before disconnecting Gen. Breaker

When the control unit has received the “delayed stop” signal, it will wait for this amount of time until it disconnects the load, i.e. the generator breaker.

The Gen Set is now running with no load and the control unit will keep it running for the cooling period.

Typical: 180 seconds (three minutes)

Range: 1 – 255 seconds


4.4.6 Cooling time

The amount of time the Gen Set is running at no load, until the control unit issues the stop-signal.

Typical: 3 minutes
Range: 0 – 30 minutes

4.5 Start/Fuel

If selecting Propulsion in the Main Tab, the *Standby Operation* tab is replaced with the *Start/Fuel* tab.



4.5.1 Initial Start Delay

When receiving the Start command from a remote slave panel, the control unit delays this amount of time before starting.

Note: If using the Preheat function, this is also the preheating timer.

Typical: 1 second (start delay), 10 seconds (preheat)
Range: 1-255 seconds

4.5.2 Cranking Time


The amount of time the starter motor is cranking the diesel engine when received the remote start signal from a slave panel.

Typical: 7 seconds
Range: 2 – 20 seconds

4.6 Speed sensor

Alt+P

This tab handles pickups and when the engine is said to be running.



4.6.1 Pickup Information

Select zero, one or two pickups.

If zero pickups are selected, one or more signals must be selected under Additional RUN Detection.

4.6.2 Pickup One/Two RPM Sender

Select if the pickup is at the flywheel or the timing gear.

- At the flywheel, set the number of pulses/revolution.
- At the timing gear, set the teeth count.

Range: 1 – 255 pulses/rev.

4.6.3 Ready to take Load

The control unit has a function that can be directed to K7 or K9 on the RK-66 R2 card – or to the optional relay cards – that activates when the engine reaches this RPM.

It will not deactivate again until the control unit reaches the stopping mode.

This can be used for any RPM detection purpose. Also see the chapter *Speed Relays* on page 36.

Typical: 1% below nominal RPM

Range: 100 – nominal RPM

4.6.4 Nominal/Max Speed

This is the nominal or maximum operating speed of the engine. For Propulsion engines, indicate the maximum speed.

Typical: 1500/1800 RPM

Range: 100 – 5000 RPM

4.6.5 Overspeed

The control unit automatically shutdowns the engine if the RPM is higher than this setting.

Typical: 15% above Nominal RPM

Range: Nominal – 6500 RPM

4.6.5.1 Overspeed Time

Typical: 0.1 seconds

Range: 0.1 – 1.0 seconds

4.6.6 RUN Detected At

When starting the gen. set., the control unit will sense that the engine is running when reached this RPM. This will also disable the cranking motor.

Typical: 400 RPM

Range: 50 – 600 RPM

4.6.7 Run Detection Delay

The delay time from when the additional RUN detection signal (eg the oil pressure switch) changes, to when this actually indicates a running engine.

4.6.8 Additional RUN Detection

In addition to the Speed Sensor, the control unit can detect that the gen. set. is running by using any of the other connected sensors. It is common practise to use the oil pressure as an additional detection of RUN.

Note: Although any signal can be selected, be sure to select *reasonable* signals – for instance Oil Pressure – for run detection.

Press OK when finished.

4.6.9 Speed Relays

Speed relays are relays that activate and deactivate at a certain RPM.

Up to four such relays can be defined, and any RPM value can be set to any relay.

The signals are routed to the MK-6 or MK-14 optional relay cards.

In the above example, Speed Relay 1 is configured. It activates at 870 RPM.


The *activated* Speed Relays – and their settings – is now available in the Relays Tab, see page 39.

4.7 Battery

Alt+B

The control unit will give an alarm if the start-battery voltage is too low.

It will not alarm during Start (Cranking state), or during Stop (Stopping state).



4.7.1 Start Battery Voltage

Select 12V or 24V supply. The control unit is a 24V system, but if a 12/24DC/DC converter is used, select 12V here.

Otherwise, always choose 24V.

4.7.2 Low Battery Voltage Alarm

This field specifies the voltage where the control unit will issue an alarm for low start-battery voltage.

Typical: 25.5 volt

24V Range: 18.0 – 30.0 volt

12V Range: 9.0 – 15.0 volt

4.7.3 Delay before Alarm

When the battery voltage is below limit, it must remain low for this period, before the alarm is given.


Typical: 60 seconds

Range: 1 – 255 seconds

4.8 Info

Alt+I

All text written in the Information Tab is displayed in the control unit when pressing the INFO button on the frontpanel.



Typical information may include:

- Project Name and Number
- Order Number
- Engine Serial Number
- Generator Serial Number
- Service Telephone Number
- Etc.

Eight lines are available with up to 40 characters on each line. The text is stored in the control unit.

4.8.1 Fields

Fields are extremely useful, and often used instead of static text.

A field will be updated with the *field content* when the configuration is downloaded into the control unit.

The following fields exist:

| Field | Field Content |
|-------------------|---|
| {filename} | The Rudolf configuration filename, without the path. |
| {date} | Today's date in short-form, YYYY-MM-DD (2002-10-30) |
| {ldate} | Today's date in long-form, YYYY-MMM-DD (2002-Oct-02) |
| {time} | The current 24h time format HH:MM (14:28) |
| {author} | Your user name in the PC (The PC name if no user name is given). |

4.9 Relays

Alt+R

On the terminal card, a number of functions are configurable to different relays as follows:

4.9.1 RK-60

There are no configurable relays available on this card. The card is used with the DCU 305 R1 system and is not configurable.


4.9.2 RK-66 R2

On the RK-66 R2 wire terminal card, the two relays K7 and K9 are configurable. See page 41 for available signals to these relays


4.9.3 MK-6 and MK-14

When necessary, optional extra relay-cards can be connected directly into the control unit.

Two types are available; the MK-6 with six relays, and the MK-14 with 14 relays.



All the available signals in the control unit can be routed to the RK-66's K7 and K9 or the MK-6 / MK-14 cards for convenient use.



The MK-6 relay card

4.9.4 Signals to the optional Relay Cards

| Relay | Signal |
|-------|--------|
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | |
| 7 | |
| 8 | |
| 9 | |
| 10 | |
| 11 | |
| 12 | |
| 13 | |
| 14 | |

MK-14
14 Relays

MK-6
6 Relays

Relay 1-6 on the MK-6 and relays 1-14 on the MK-14 can be given any signal from the following signal pool:

4.9.5 Available configurable signals

| # | Signal | Comment |
|----|---------------------------|--|
| 1 | Start failure | The engine did not start after final start attempt. |
| 2 | Engine stopped | The engine stopped for no known reason. |
| 3 | Overspeed | Engine speed too high. Stays until Acknowledged. |
| 4 | Start battery low voltage | The engines start battery has low voltage. |
| 5 | Stop failure | A stop signal was given but after 40 seconds, the engine is still running. |
| 6 | Secondary battery failure | The secondary battery is not connected or its voltage is below 12V. |
| 7 | Current overload | The sensor fuse is blown. The fuse resets itself when the short circuit is removed. |
| 8 | Pickup failure | Unable to detect a valid pickup signal. Dependent upon at least one defined <i>Additional RUN Detection</i> . Sum of pickup 1 and 2. |
| 9 | Analogue Sensor failure | An analogue input (4-20mA) is defined but the signal is less than 2mA. |
| 10 | Preheat | Preheating before and during start attempts. Stays on until engine has started or failed to start. |
| 11 | Start command | Same as the input Blackout signal, e.g. from main switchboard. (Input terminal T34) |
| 12 | Engine started | The control unit detects the engine is running but no start signal has been detected. |
| 13 | Manual stop | Manual Stop button, local or remote. |
| 14 | Delayed stop | The control unit has received signal saying the gen. set may stop. |
| 15 | Cooling | The gen. set. is cooling and running at no load. |
| 16 | Lampstest button | Manual press of the Lampstest button. |
| 17 | Acknowledge button | Manual press of the Acknowledge button. |
| 18 | Standby mode | The control unit is set to Standby (Automatic) mode. |
| 19 | Manual mode | The control unit is set to Manual mode. |
| 20 | Buzzer off button | Manual press of the Buzzer Off button. |
| 21 | Ready to start | The gen. set. is ready to start. |
| 22 | Cranking | The control unit signals the start motor. The gen. set. is cranking. On also between start attempts. |
| 23 | Running | The gen. set is running. On as long as the engine is running. Same as green LED in the Start button. |
| 24 | Stopping | The control unit signals the stop solenoid and the engine is stopping. |
| 25 | Stopped | The engine has stopped (Rpm < 10). |
| 26 | Shutdown override | The control unit is disabling shutdowns, except |

| # | Signal | Comment |
|----|----------------------------|--|
| | | overspeed. |
| 27 | Start disabled | The control unit is disabling local and remote start attempts, also when set to Standby. |
| 28 | First start attempt failed | The <i>first</i> of several start attempts failed during automatic start. |
| 29 | Pending alarm(s) | One or more alarms present. May be acknowledged. |
| 30 | Buzzer | Active when buzzer is active |
| 31 | Common Warning | Sum of all warning channels, plus any internal warning |
| 32 | Common Alarm | Sum of all alarm channels, plus any internal alarm |
| 33 | Common Shutdown | Sum of all shutdown channels, plus any internal shutdown |
| 34 | Backup System Failure | The built-in backup system has failed. |
| 35 | Disconnect Gen. Breaker | Disconnects the generator breaker when entering cooling or stopping mode. |
| 36 | Downloading parameters | New parameters are being downloaded into the control unit. |
| 37 | Power On | Activated when the control unit is powered. |
| 38 | Ready to take load | Activates – and stays activated – when reached a certain rpm. |
| 39 | Local Mode | Control Unit is set to Local Mode |

Further, all channels configured to give a warning, alarm or shutdown, can be routed to any relay.

The relay activates when there is a warning, alarm or shutdown event.

4.9.6 Disable Broken Wire Alarm on Terminal 44

The control unit alarms if the coil on the relay connected to terminal 44 (shutdown) is broken.

Tick this option to disable the alarm that appears if no relay is connected to terminal 44.

<end>