

## Instructions for exchanging old DCU-105 to new DCU-205:

- Cut 24 VDC power.
- Remove DCU-105, cable, and terminal board, and replace with DCU-205, new cable and new terminal card.
- Make sure all cables to the old terminal card is connected to exact same terminal on the new terminal card.
- Connect a wire between terminal 1-39, and between terminal 2-40.\*
- Switch on the 24 VDC power, and you are up.

\* This because The DCU-205 needs two 24 VDC supplies. The second supply is on terminal 39 and 40 (See manual for additional instructions.).