What's in the Box?

- 1. RP 210E/220E in an ESD Bag
- 2. Cabinet Frame
- 3. Bag with fastening material
- 4. RJ45 Connector (IP rated)
- 5. Quick Installation Guide







Handle with care when opening the bag and installing the unit.

Instrument Pages Configurable Gauges and Bar-graphs.

User Interface Basics

Select Page Thumbnails for quick selection.

Home & Alarm buttons located at the upper right side of the panel.

Start & Stop Engine buttons located at the lower right side of the panel. (N/A for RP 206E – no Start/Stop buttons)

Alarm List

Red:Alarms/ShutdownsYellow:WarningsWhite:Other messagesBold:Unconfirmed

Menu

The Menu hierarchy. There may be several RP panels in a network but only one is in control. This is indicated by a star (\bigstar) .

For More Information:

For the latest updated information, please contact your local distributor or visit the Marine Pro 200 section of the Auto-Maskin web site: <u>http://www.auto-maskin.com</u>















Marine Pro. 200

Quick Installation Guide

RP 206E	P/N 1006478
RP 210E	P/N 1006476
	P/N 1006474
RP 220E	P/N 1006472

Engine Remote Panel



- Hi res 5.7" touchscreen
- Ethernet communication for connection to network and/or DCU engine panel
- 12V or 24V power supply
- USB Port
- IP56 rated enclosure
- Multilanguage support
- Configurable templates

Measurements

Section	Width	Height	Depth	Unit
Size	167	135	68	mm
Cut out	155	123	90	mm

Power Ratings

Section	Min	Тур.	Max	Unit
Power	8	12/24	32	VDC
Supply, Vcc	-	0.4	2	Α

Max ripple 10% without exceeding Min and Max values.

Rear side and Connectors



Responsibilites:

It is the <u>sole responsibility of the installer</u> to ensure that the installation work is carried out in a satisfactorily manner and meet all applicable rules and regulations.

Installation Steps

Configuration Steps

- 1. Remove the unit from the ESD Bag. Use the submitted Cabinet Frame and mount it in a suitable enclosure.
- 2. Attach the Power Supply connector (CON1) and make sure the power ratings are within product specifications.
- 3. Attach All Faults Relay (CON2).
- 4. Use additional sealed DT connectors and the submitted RJ45 Connector kit to ensure the IP rating.

A Connector Kit (P/N: 1006479) with four Deutsch DT-connectors, crimp sockets and sealing plugs is available. See the Installation Manual for further information. At the first Power-Up the user will be guided through a Setup Wizard:

- 1. Language selection and your choice is valid through the rest of the procedure.
- 2. Network settings. Make sure to follow common network configuration practice and take care when several units need to operate within the same network.

PC Connection/Setup:

- Connect via Ethernet using a Net Browser
- From the Address Field in the Browser, type the IP-Address. Factory Default is **192.168.0.201.**
- Then log in to the unit. The Factory Default password is '**1234'**. (No User Name).

For further details and information, please see the Configuration Manual.

Note:

Auto-Maskin continuously upgrades its products and reserves the right to make changes and improvements without prior notice.

Additional Documentation:

Please visit the Marine Pro 200 section of the Auto-Maskin web site for the following enhanced documentation:

- Installation Manual
- Configuration Manual
- User's Manual.

http://www.auto-maskin.com