

What's in the Box?

1. RIO 425 AC Generator Interface
2. 120 Ohm Resistor
3. Quick Installation Guide




Caution!

Handle with care when opening the bag and installing the units.

User Interface Basics

Instrument Page

When connected and configured the DCU engine panel displays this power measurement instrument page.



Note!

It is recommended to configure the unit using the interface on a DCU engine panel.

However, the product has a local user interface briefly explained below:

Reset/Setup

Press the reset key and the Setup key for 5 seconds to enter the Setup menu.



Clear

Clearing the energy counters or maximum value of Pd.



Enter

Validates information and moves to the next menu.



Min

Move cursor among digits.



Max

Select menu options or increase a digit in a variable.



- Phase/L1-L3 up to 520 VAC
- Phase/N up to 300 VAC
- Phase currents (A)
- Frequency (Hz)
- Power factor
- Total power (kW)
- Local Display
- Configurable
- Power supply 85-265 V
- Modbus RTU/RS-485

